

7. Safety Precaution

1. Usage Caution

★ Avoid damage to product caused by heavy pressure, strong vibration or immersion during transportation, storage and installation.

★ Cover of this product is made of organic materials. Do not expose it to any liquid, gas or solids which may corrode the shell.

★ Do not expose the product to rain or moisture.

Wipe the lens with a soft, dry cloth gently and use a mild detergent if necessary.

★ Do not use strong or corrosive detergents to avoid scratching the lens and affecting the image;

★ Any damage caused by dismantling the product by user without permission is not covered by warranty.

2. Electrical Safety

★ Installation and use of this product must strictly comply with local electrical safety standards.

★ Do not use a power adapter that exceeds the power specification, otherwise it will cause the device components to burn out and not work properly

★ When using the product, keep a sufficient distance from strong electrical equipment, and take protective measures such as lightning protection and surge protection when necessary.

★ Please turn off the power switch when the product is not in use, and unplug the power adapter from the power socket at the same time.

3. Install

★ Do not rotate the camera head violently, otherwise it may cause mechanical failure.

★ This product should be placed on a stable desktop or other horizontal surface. Do not install the product obliquely, otherwise it may display inclined image.

★ Ensure there are no obstacles within rotation range.

★ Do not power on before completely installation.

4. Magnetic Interference

Electromagnetic fields at specific frequencies may affect the video image. This product type is Class A, which may cause radio interference in household application, thus appropriate measure is required to avoid magnetic interference.